#### **Cementing Products**



# Sure-Seal 3<sup>™</sup> Flow-Activated Auto-Fill Device


Weatherford's flow-activated auto-fill device allows casing to fill automatically while running in the hole. This device is designed for installation on *Sure-Seal 3* float valves and can be retrofitted to existing float equipment with a single *Sure-Seal 3* valve.


#### **Applications**

• Provide auto-fill while running-in, and backpressure and flow during cementing operations

#### Features, Advantages and Benefits

- The versatile design accommodates 2 1/2-in. and 3 1/4-in. cemented *Sure-Seal* 3 valves on float collars and float shoes.
- This device automatically fills casing at rates of up to 15 bbl/min, providing a time- and cost-saving solution by increasing running speed and reducing surge on the formation.
- Circulation rates of up to 3 bbl/min without deactivation of the auto-fill device are possible.
- The auto-fill device is de-activated at flow rates of 7 bbl/min and above, and features a retaining mechanism that prevents separation of the device from the valve, preventing it from interfering with equipment further down in the well.
- The impeller is compact and robust with all-plastic construction, promoting durable, worry-free operation.
- The *Sure-Seal 3* auto-fill device is PDC drillable to save time and money during drillout operations.








## Sure-Seal 3<sup>TM</sup> Flow-Activated Auto-Fill Device

### **Specifications**

Maximum temperature rating of impeller (°F/°C)	400 <i>204</i>
Maximum recommended fill-up rate	4 1/2-in. to 7 5/8-in. casing: 10 bbl/min
	8 5/8-in. and larger casing: 15 bbl/min
De-activation flow rate	4 1/2-in. to 7 5/8-in. casing: 4 to 6 bbl/min
	8 5/8-in and larger casing: 5 to 7 bbl/min
Maximum circulation flow rate without de-activation	3 bbl/min
Maximum temperature rating of float equipment without device (°F/°C)	400 204

#### **Options**

- The Sure-Seal 3 auto-fill device can arrive completely assembled and installed onto the float equipment, ready for use.
- A field kit is also available to retrofit the auto-fill device onto existing float equipment containing a single *Sure-Seal 3* valve in which the valve is already cemented into the float equipment.



Weatherford products and services are subject to the Company's standard terms and conditions, available on request or at weatherford.com. For more information contact an authorized Weatherford representative. Unless noted otherwise, trademarks and service marks herein are the property of Weatherford. Specifications are subject to change without notice. Weatherford sells its products and services in accordance with the terms and conditions set forth in the applicable contract between Weatherford and the client.